

SPARE PARTS LIST

MODEL NO. DTD147

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	187388-6	HOUSING SET INC. 35	1	
002	815F42-5	DTD147 NAME PLATE	1	
003	266130-9	TAPPING SCREW BIND PT 3X16	9	
004	419041-9	F/R CHANGE LEVER	1	
005	141448-8	SWITCH COMPLETE	1	
006	619353-2	ROTOR	1	
007	632A40-2	STATOR UNIT	1	
008	620136-5	LED CIRCUIT	1	
009	643860-3	TERMINAL	1	
010	231951-8	RING SPRING 11	1	
011	267085-1	FLAT WASHER 12	1	
012	233005-7	COMPRESSION SPRING 13	1	
013	326072-0	BIT SLEEVE	1	
014	424495-7	BUMPER	1	
015	453664-3	HAMMER CASE COVER	1	
016	141477-1	HAMMER CASE COMPLETE	1	
017	261151-6	NYLON WASHER 19	1	
018	216001-0	STEEL BALL 3.5	2	
019	326071-2	ANVIL M	1	
020	326054-2	HAMMER	1	
021	216001-0	STEEL BALL 3.5	24	
022	267175-0	FLAT WASHER 24	1	
023	234251-5	COMPRESSION SPRING 25	1	
024	346466-3	PLATE	1	
025	216011-7	STEEL BALL 5.6	2	
026	227233-4	SPUR GEAR 22	2	
027	326066-5	SPINDLE	1	
028	256253-1	PIN 5	2	
029	253362-7	THIN WASHER 12	1	
030	227150-8	INTERNAL GEAR 51	1	
031	211140-1	BALL BEARING 6901LLB	1	
032	213507-9	O RING 40	1	
033	158145-9	BEARING BOX COMPLETE INC. 31	1	
035	187388-6	HOUSING SET INC. 1	1	
036	141583-2	SWITCH PLATE COMPLETE	1	
037	453665-1	BAFFLE PLATE	1	
A01	346317-0	HOOK	1	
A02	266622-8	+ TRUSS HEAD SCREW M4X12	1	
A03	***DC18RC	DC18RC FAST CHARGER	1	
A04	196015-4	BATTERY BL1830 SET	2	
A05	450128-8	BATTERY COVER	1	
A06	824979-9	PLASTIC CARRYING CASE	1	
A07	802U46-6	DTD147RFE PLASTIC CASE LABEL	2	

SERVICE DRAWING

MODEL NO. DTD147

