

SPARE PARTS LIST

MODEL NO. BML800

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	GM00001223	LAMP HD FRONT ASSY ROS28009800	1	
002	GM00001210	LAMP HEAD ASSY ROS28009801	1	
003	GM00001224	SCREW 3.5X30 PM B0135300004	1	
004	GM00001225	ANGLE LOCK C4120800002	2	
005	GM00001226	SPRING B1303800920	2	
006	GM00001227	HEX. NUT B0203020000	1	
007	GM00001228	BELT CLIP ASSY ROS28009802	1	
008	GM00001229	SCREW 2.3X8 PWB B0123080706	2	
009	GM00001230	HOLDER FOR FERRITE C4120800003	1	
010	GM00001231	MAGNET RING A2301005700	1	
011	GM00001229	SCREW 2.3X8 PWB B0123080706	2	
012	GM00001233	CABLE GUARD C0120800007	1	
013	GM00001234	MAIN CIRCUIT ROS28009803	1	
014	GM00001235	SWITCH CIRCUIT ROS28009804	1	
015	GM00001117	BATTERY HOLDER C2010239007	1	
016	GM00001236	SWITCH COVER ASSY ROS28009805	1	
017	GM00001189	SCREW 3X12BB (B0130120712)	3	
018	GM00001237	BODY ASSY ROS28009806	1	
019	GM00001380	SILICON BAND ASSY ROS28009808	1	

SERVICE DRAWING

MODEL NO. BML800

