

SPARE PARTS LIST

MODEL NO. 5477NB

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	266400-6	HEX. SOCKET HEX. BOLT M8X20	1	
002	224275-9	OUTER FLANGE 40	1	
003	224268-6	INNER FLANGE 40	1	
004	257279-6	RING 17	1	
005	961201-4	RETAINING RING S-42	1	
006	231889-7	TENSION SPRING 5	1	
007	318068-5	SAFETY COVER	1	
008	346880-3	SPACER	1	
009	346004-1	LEVER PLATE	1	
010	266026-4	TAPPING SCREW BIND CT 4X12	1	
012	318328-5	BLADE CASE	1	
013	251350-8	+ COUNTERSUNK HEAD SCREW M6X28	1	
014	262553-9	RUBBER SLEEVE 6	1	
015	266036-1	TAPPING SCREW BIND CT 5X20	3	
016	285809-3	BEARING RETAINER 23-36	1	
017	211251-2	BALL BEARING 6003LLB	1	
018	324958-2	SPINDLE	1	
019	254001-2	WOODRUFF KEY 4	1	
020	140706-9	GEAR HOUSING COMPLETE	1	
021	911228-4	PAN HEAD SCREW M5X18	2	
022	421970-4	DECOMPRESSION CHAMBER	1	
023	318079-0	PLATE	1	
024	911228-4	PAN HEAD SCREW M5X18	2	
025	256501-8	SHOULDER PIN 6	1	
026	213005-3	O RING 5	1	
027	911228-4	PAN HEAD SCREW M5X18	3	
028	213005-3	O RING 5	1	
029	253145-5	FLAT WASHER 6	1	
030	233011-2	COMPRESSION SPRING 8	1	
031	419589-1	CAP	1	
032	419578-6	GRIP	1	
033	911228-4	PAN HEAD SCREW M5X18	2	
035	911323-0	PAN HEAD SCREW M6X16	1	
036	419572-8	COVER	1	
037	318066-9	BEARING BOX	1	
038	213676-6	O RING 53	1	
039	210107-6	BALL BEARING 6001ZZ	1	
040	253744-3	FLAT WASHER 12	1	
041	227504-9	HYPOID GEAR 36	1	
042	240005-0	FAN 45	1	
043	210067-2	BALL BEARING 6000ZZ	1	
044	681640-9	INSULATION WASHER	1	
045	516984-7	ARMATURE ASS'Y 240V INC. 43,44,46-51	1	
046	241905-7	FAN 80	1	
047	285727-5	BEARING RETAINER	1	
048	211251-2	BALL BEARING 6003LLB	1	
049	213226-7	O RING 16	1	
050	257198-6	RING 17	1	
051	961077-9	RETAINING RING S-17	1	
052	266373-3	TAPPING SCREW 5X35	4	
053	419573-6	BAFFLE PLATE	1	
054	266418-7	TAPPING SCREW 5X55	2	
055	526174-4	FIELD ASS'Y 240V	1	
056	163540-0	DEPTH GUIDE	1	
057	941201-0	FLAT WASHER 8	1	
058	264006-4	HEX. NUT M8-13	1	
059	346003-3	LEVER PLATE	1	
060	257953-6	BOW STOP RING E-12	1	
061	265965-5	CAP SQUARE NECK BOLT M8X24	1	
062	931402-8	HEX. NUT M8	1	

SPARE PARTS LIST

MODEL NO. 5477NB

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
063	942201-3	SPRING WASHER 8	1	
064	253731-2	FLAT WASHER 8	1	
065	941201-0	FLAT WASHER 8	1	
066	264006-4	HEX. NUT M8-13	1	
067	346003-3	LEVER PLATE	1	
068	257953-6	BOW STOP RING E-12	1	
069	213118-0	O RING 12	1	
070	345677-7	STOPPER PLATE	1	
071	265163-1	+ FLAT HEAD SCREW M8	1	
072	266213-5	H.S.SET SCREW(FLAT POINT)M5X12	1	
073	266213-5	H.S.SET SCREW(FLAT POINT)M5X12	1	
074	931302-2	HEX. NUT M6	1	
075	942151-2	SPRING WASHER 6	1	
076	941151-9	FLAT WASHER 6	1	
077	168806-3	BASE	1	
078	265041-5	+ FLAT HEAD SCREW M6	1	
080	253022-1	FLAT WASHER 8	1	
081	158805-3	MOTOR HOUSING COMPLETE	1	
082	865939-2	5477NB NAME PLATE	1	
083	643650-4	BRUSH HOLDER CAP 6.5-13.5	2	
084	181044-0	CARBON BRUSH CB-153	1	
089	188185-3	HANDLE SET INC. 93	1	
090	266459-3	TAPPING SCREW 5X25	4	
091	266326-2	TAPPING SCREW 4X18	2	
092	651189-3	SWITCH TG933TN-2	1	
093	188185-3	HANDLE SET INC. 89	1	
094	266427-6	TAPPING SCREW 4X12	2	
095	687673-2	STRAIN RELIEF	1	
096	682564-2	CORD GUARD	1	
097	695123-3	POWER SUPPLY CORD 1.5-2-4.0	1	
098	961056-7	RETAINING RING S-16	1	
099	232247-0	CONED DISC SPRING 16	2	
A01	D-45917	TCT SAW BLADE F WOOD 185X30X20	1	
A02	783204-6	HEX. WRENCH 6	1	
A03	257343-3	RING 16	1	

SERVICE DRAWING

MODEL NO. 5477NB

