

# SPARE PARTS LIST

MODEL NO. EM4351UH

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	168712-2	CLUTCH DRUM	1	
002	962201-7	RETAINING RING (INT) R-42	1	
003	211387-7	BALL BEARING 6004LLU	1	
004	961090-7	RETAINING RING (EXT) WR-20	1	
005	318849-7	CLUTCH CASE	1	
006	922331-6	HEX. SOCKET HEAD BOLT M6X20	4	
007	424488-4	BUFFER RUBBER	2	
008	922201-9	HEX. SOCKET HEAD BOLT M5X8	1	
009	922351-0	HEX. SOCKET HEAD BOLT M6X30	1	
010	456033-7	HANGER	1	
011	346572-4	HANGER HOLDER L	1	
012	346571-6	HANGER HOLDER R	1	
013	266957-7	WING BOLT M5X20	1	
014	168796-0	KNOB 57	1	
015	318425-7	HANDLE CLAMP	1	
017	318860-9	HANDLE HOLDER	1	
018	233309-7	COMPRESSION SPRING 17	1	
019	453526-5	PIPE HOUSING	1	
020	453528-1	HOUSING HOLDER	1	
021	922226-3	HEX. SOCKET HEAD BOLT M5X18	1	
022	346590-2	PIPE CLAMP 33	1	
023	424488-4	BUFFER RUBBER	2	
024	266429-2	TAPPING SCREW 3X16	2	
025	453527-3	HOUSING COVER	1	
026	819312-8	MAKITA LOGO LABEL	1	
027	801R67-7	CAUTION LABEL	1	
028	814K20-2	SERIAL NO. LABEL	1	
029	141335-1	SHAFT PIPE COMPLETE	1	
030	443146-3	FELT RING 8	1	
031	326153-0	SHAFT	1	
032	141584-0	HANDLE COMPLETE	1	
033	911256-9	PAN HEAD SCREW M5X35	1	
046	413143-3	WASHER	2	
047	452259-9	PROTECTOR	1	
048	266326-2	TAPPING SCREW 4X18	1	
049	346074-0	CUTTER	1	
050	135398-7	PROTECTOR EXTENSION ASSY INC. 48,49	1	
051	346072-4	PROTECTOR CLAMP	1	
052	451090-0	PROTECTOR COVER	1	
053	266579-3	HEX SOCKET HEAD BOLT M6X30	2	
054	266865-2	H.S.H.BOLT M5X14 WITH WR	2	
055	126260-7	GEAR CASE ASSEMBLY INC. 56-64,68-73	1	
056	213459-4	O RING 32	1	
057	188865-1	CUTTER SHAFT SET	1	
058	211064-1	BALL BEARING 6000	1	
059	211062-5	BALL BEARING 6000ZZ	1	
060	961006-2	RETAINING RING S-10	1	
061	962105-3	RETAINING RING R-26	1	
062	922353-6	HEX.SOCKET HEAD BOLT M6X30	1	
063	265590-2	+HEX.BOLT M8X10 WITH R	1	
064	210081-8	BALL BEARING 629ZZ	1	
068	210116-5	BALL BEARING 6201LLU	1	
069	962151-6	RETAINING RING R-32	1	
070	332114-0	RECEIVE WASHER	1	
071	346355-2	CLAMP WASHER	1	
072	168526-9	CUP	1	
073	264025-0	HEX. NUT M10-17	1	
074	126114-8	CONTROLL LEVER ASSEMBLY INC. 75-86,88,89	1	

# SPARE PARTS LIST

MODEL NO. EM4351UH

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
075	183A09-4	LEVER CASE SET INC. 87	1	
076	233540-5	TORSION SPRING 11	1	
077	451084-5	THROTTLE LEVER	1	
078	233541-3	TORSION SPRING 7	1	
079	451083-7	LOCK OFF LEVER	1	
080	453524-9	CORRUGATE TUBE	1	
081	168711-4	CONTROL CABLE	1	
082	451081-1	CABLE HOLDER	1	
083	451500-7	SWITCH LEVER	1	
084	232251-9	LEAF SPRING	1	
085	455723-9	SWITCH COVER	1	
086	638972-5	LEAD UNIT	1	
087	183A09-4	LEVER CASE SET INC. 75	1	
088	266326-2	TAPPING SCREW 4X18	3	
089	638973-3	LEAD UNIT	1	
101	922233-6	HEX SOCKET HEAD BOLT M5X20	1	
102	424302-4	PLUG CAP	1	
103	455103-9	CYLINDER COVER	1	
104	922233-6	HEX SOCKET HEAD BOLT M5X20	1	
105	453536-2	MUFFLER COVER	1	
106	265995-6	TAPPING SCREW 4X18	2	
107	922332-4	HEX. SOCKET HEAD BOLT M6X20	3	
108	168715-6	EXHAUST MUFFLER	1	
109	346574-0	MUFFLER GASKET	1	
110	331987-8	EXHAUST PORT SPACER	1	
111	922226-3	HEX. SOCKET HEAD BOLT M5X18	4	
112	318850-2	ROCKER COVER OUTER	1	
113	422091-5	TUBE 5-160	1	
114	454424-6	CORRUGATE TUBE	1	
115	453529-9	ROCKER COVER INNER	1	
116	162335-8	ROCKER COVER GASKET	1	
117	324891-8	PLUG CAP SPRING	1	
118	168401-9	SPARK PLUG	1	
119	422090-7	TUBE 3-85	1	
120	452049-0	SPACER	2	
121	135659-5	CYLINDER BLOCK ASS'Y INC. 122-124	1	
122	424200-2	SPACER	2	
123	424201-0	CHECK VALVE	2	
124	922342-1	HEX. SOCKET HEAD BOLT M6X25	8	
125	422099-9	PIPE	1	
126	282020-8	HOSE CLAMP	1	
127	424301-6	OIL TUBE	1	
128	325666-8	OIL WEIGHT	1	
129	162337-4	OIL CASE GASKET	1	
130	266760-6	H.S.H.BOLT M5X18 WITH WRM	3	
131	452047-4	OIL CAP	1	
132	424343-0	GASKET	1	
133	453538-8	OIL PIPE	1	
134	162338-2	OIL PIPE GASKET	1	
135	318854-4	OIL CASE	1	
136	922226-3	HEX. SOCKET HEAD BOLT M5X18	4	
137	346305-7	GASKET	1	
138	266611-3	HEX BOLT M6X8	1	
139	346398-4	LEAD VALVE	1	
140	318851-0	RETAINER PLATE	1	
141	922226-3	HEX. SOCKET HEAD BOLT M5X18	1	
142	325665-0	JOINT PIPE	1	
143	168724-5	TUBE COMPLETE	1	

# SPARE PARTS LIST

MODEL NO. EM4351UH

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
144	454426-2	SPIRAL TUBE 6-80	1	
145	163518-3	GASOLINE FILTER	1	
146	282020-8	HOSE CLAMP	1	
150	126119-8	STARTER COVER ASSEMBLY INC. 151-157	1	
151	266634-1	SET SCREW M6X20	1	
152	452288-2	REEL	1	
153	232262-4	SPIRAL SPRING	1	
154	424361-8	STARTER KNOB	1	
155	424360-0	ROPE STOPPER	1	
156	444027-4	STARTER ROPE	1	
157	453534-6	STARTER COVER	1	
158	922233-6	HEX SOCKET HEAD BOLT M5X20	4	
160	126116-4	ROCKER ARM ASSEMBLY	2	
161	331990-9	COTTER	4	
162	331991-7	RETAINER	2	
163	234238-7	COMPRESSION SPRING 11	2	
164	256200-2	PIN 5	1	
165	256866-8	ROD 2.5	2	
166	268238-5	PIN 5	1	
167	313236-5	CAM LIFTER	2	
168	256186-0	PIN 5	1	
169	126571-0	CAMGEAR ASSEMBLY	1	
170	261127-3	TEFLON WASHER 10	1	
171	326498-6	EXHAUST VALVE	1	
172	326157-2	INTAKE VALVE	1	
173	196667-1	PISTON RING SET	1	
174	233983-1	CLIP	2	
175	318853-6	PISTON	1	
176	268285-6	PISTON PIN	1	
177	213685-5	OIL SEAL 12	1	
178	126121-1	CRANK SHAFT ASSEMBLY INC. 177,180,181	1	
179	254040-2	WOODRUFF KEY 3	1	
180	267425-3	FLAT WASHER 26	1	
181	213537-0	OIL SEAL 12	1	
182	266086-6	HEX. SOCKET HEAD BOLT M5X16	4	
183	318856-0	CAM GEAR COVER	1	
184	162334-0	CAM GEAR COVER GASKET	1	
185	638974-1	LEAD UNIT	1	
186	638975-9	LEAD UNIT	1	
187	444021-6	TUBE	1	
188	168714-8	IGNITION COIL	1	
189	266602-4	HEX. SOCKET HEAD BOLT M4X20	2	
190	126122-9	FLYWHEEL COMPLETE	1	
191	264039-9	CONED DISK SPRING HEXNUT M8-13	1	
192	125728-0	FUEL TANK CAP ASSEMBLY	1	
194	810455-9	CAUTION PLATE	1	
195	424081-4	BUFFER RUBBER	1	
196	897220-3	SERIAL NO. LABEL	1	
198	922233-6	HEX SOCKET HEAD BOLT M5X20	1	
199	261152-4	RUBBER WASHER 8	1	
200	331988-6	SPACER	1	
201	168875-4	FUEL TANK	1	
202	922332-4	HEX. SOCKET HEAD BOLT M6X20	4	
203	318852-8	ENGINE BASE	1	
204	266597-1	SHOULDER HEX. BOLT M8	2	
205	267832-0	WAVE WASHER 10	2	
206	313238-1	CLUTCH SHOE	2	
207	231880-5	TENSION SPRING 5	2	
208	267428-7	FLAT WASHER 8	2	

# SPARE PARTS LIST

MODEL NO. EM4351UH

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
209	313239-9	CLUTCH BASE	1	
210	346576-6	FAN PLATE	1	
211	266461-6	H.S.BUTTON HEAD SCREW M5X8	2	
212	453530-4	MUFFLER PLATE	1	
213	266760-6	H.S.H.BOLT M5X18 WITH WRM	1	
214	345918-1	HOSE CLAMP	1	
215	126474-8	CLEANER COVER ASSEMBLY INC. 216,217	1	
216	266743-6	HEX.SOCKET HEAD BOLT M5X20	1	
217	898844-8	INDICATION LABEL	1	
218	442181-8	AIR CLEANER ELEMENT	1	
219	266601-6	HEX. SOCKET HEAD BOLT M5X60	2	
220	443173-0	AIR CLEANER ELEMENT	1	
221	126117-2	CLEANER PLATE ASSEMBLY INC. 222-226	1	
222	162346-3	SEPARATOR PLATE	1	
223	352020-3	SEPARATOR MESH	1	
224	266007-8	TAPPING SCREW BIND PT 3X10	1	
225	453865-3	SEPARATOR CASE	1	
226	424316-3	CHECK VALVE	2	
227	454425-4	SPIRAL TUBE 6-100	1	
228	422074-5	TUBE 3-120	1	
229	168398-2	PRIMER PUMP	1	
230	442196-5	CARBURETOR GASKET	1	
231	123301-0	CARBURETOR ASSEMBLY	1	
232	345963-6	CLAMP	1	
233	266388-0	TAPPING SCREW 5X16	1	
234	442197-3	CARBURETOR GASKET	1	
235	266814-9	HEX SOCKET HEAD BOLT M5X20	2	
236	424489-2	GROMMET	1	
237	422080-0	TUBE 3-35	1	
238	142736-6	INSULATOR COMPLETE	1	
239	213642-3	O-RING 18	1	
240	819430-2	CAUTION TAG	1	
241	898805-8	EM4351UH MODEL NO. LABEL	1	
242	451825-9	CLAMP	1	
243	WJ00096589	SCREW ASSEMBLY	1	
244	WJ00021158	COVER-METERING DIAPHRAGM	1	
245	168620-7	METERING DIAPHRAGM	1	
246	442183-4	METERING DIAPHRAGM GASKET	1	
247	WJ00014477	PIN-METERING LEVER	1	
248	WJ00016648	LEVER	1	
249	WJ00983248	SPRING	1	
250	5416036160	PLUG-WELCH	1	
251	WJ00088229	PLUG-CUP	1	
252	5806084330	STEEL BALL	1	
253	WJ00160593	ACCELERATOR PISTON ASSEMBLY	1	
254	WJ00983305	SPRING	1	
255	WJ00963240	SCREW	1	
256	WJ00343562	THROTTLE VALVE	1	
257	WJ01024009	NEEDLE (HIGH)	1	
258	WJ01024008	NEEDLE IDLE	1	
259	5106038120	WASHER	1	
260	257964-1	STOP RING E-3	1	
261	WJ00098494	SPRING	1	
262	WJ00224392	THROTTLE SHAFT ASSEMBLY	1	
263	413140-9	WASHER	1	
264	5246001210	SWIVEL	1	
265	5016004110	SCREW	1	
266	WJ00008282	VALVE-INLET NEEDLE	1	
267	WJ00001673	RING-RETAINING	1	


# SPARE PARTS LIST

MODEL NO. EM4351UH

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
268	WJ00183585	CHOKE LEVER	1	
269	WJ00044456	CHOKE SHAFT	1	
270	5806122210	SPRING	1	
271	5806122220	BALL	1	
272	WJ00006295	CHOKE VALVE	1	
273	WJ00096475	SCREW	1	
274	352010-6	INLET SCREEN	1	
275	WJ00009589	DIAPHRAGM-PUMP	1	
276	WJ00092228	GASKET	1	
277	234183-6	CONICAL COMPRESSION SPRING 5-9	1	
278	WJ00213807	PUMP COVER ASSEMBLY	1	
279	WJ00096166	SCREW	1	
280	WJ00098217	SPRING	1	
281	WJ00096368	IDLE ADJUST SCREW	1	
282	455102-1	CHANGE PLATE	1	
283	266385-6	TAPPING SCREW 4X14	1	
284	267485-5	FLAT WASHER 5	2	
285	257903-1	STOP RING E-2.3	1	
286	941101-4	FLAT WASHER 5	1	
A01	196129-9	BAND ASSEMBLY SET	1	
A02	451252-0	TOOL COVER	1	
A03	195501-2	OIL SET	1	
A04	782233-6	BOX DRIVER 10-16	1	
A05	783223-2	HEX. WRENCH 4	1	
A06	783232-1	HEX. WRENCH 5	1	
A07	782238-6	BOX WRENCH 17	1	
A08	831304-7	ACCESSORY BAG	1	
A09	122882-1	CUTTER ASSEMBLY	1	
E02	WJ00098404	SPRING	2	


# SERVICE DRAWING

MODEL NO. EM4351UH




# SERVICE DRAWING

MODEL NO. EM4351UH



# SERVICE DRAWING

MODEL NO. EM4351UH





# SERVICE DRAWING

MODEL NO. EM4351UH

