

# SPARE PARTS LIST

MODEL NO. BHR200

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	286265-0	CAP 31	1	
002	417299-4	CHUCK COVER	1	
003	233203-3	COMPRESSION SPRING 38	1	
004	231936-4	RING SPRING 30.5	1	
005	323819-3	SPRING GUIDE	1	
006	233234-2	COMPRESSION SPRING 35	1	
007	232190-3	LEAF SPRING 26	1	
008	231979-6	RING SPRING 17	1	
009	256447-8	PIN 8	1	
010	323820-8	CHUCK RING	1	
011	344690-2	GUIDE WASHER	1	
012	213360-3	OIL SEAL 25	1	
013	961105-0	RETAINING RING S-25	1	
014	231987-7	RING SPRING 21	1	
015	323846-0	O RING CASE	1	
016	213117-2	O RING 11	1	
017	213125-3	O RING 12	1	
018	257231-4	RING 12	1	
019	324015-6	IMPACT BOLT	1	
020	213124-5	O RING 12	1	
021	214405-0	PLANE BEARING 26	1	
022	324014-8	TOOL HOLDER	1	
023	216022-2	STEEL BALL 7.0	1	
024	227002-3	SPUR GEAR 49	1	
025	233109-5	COMPRESSION SPRING 29	1	
026	267132-8	FLAT WASHER 29	1	
027	231962-3	RING SPRING 26	1	
028	211377-0	BALL BEARING 6905LLB	1	
029	324016-4	STRIKER	1	
030	213230-6	O RING 15	1	
031	317380-0	PISTON CYLINDER	1	
032	267104-3	FLAT WASHER 12	1	
033	324017-2	PISTON JOINT	1	
034	267104-3	FLAT WASHER 12	1	
035	211012-0	BALL BEARING 606ZZ	1	
036	344905-7	CUP WASHER 6	1	
037	231999-0	CONICAL COMP. SPRING 7-14	1	
038	226399-7	SPUR GEAR 10	1	
039	323988-0	CLUTCH CAM	1	
040	324018-0	CAM SHAFT	1	
041	219014-0	SWASH BEARING 10	1	
042	226792-5	ZEROL BEVEL GEAR 32	1	
043	210022-4	BALL BEARING 626DDW	1	
044	257235-6	RING 6	1	
046	344901-5	GRIP SPRING 50	1	
047	266250-9	CUP SQUARE NECK BOLT M8X50	1	
048	852433-3	NAME PLATE BHR200	1	
049	265995-6	TAPPING SCREW 4X18	14	
050	183891-5	HOUSING SET INC. 88,89	1	
051	344898-8	SUPPORT PLATE	1	
052	643955-2	TERMINAL	1	
053	417291-0	SWITCH LEVER	1	
054	651990-6	SWITCH TG523BFSB-1	1	
055	911006-2	PAN HEAD SCREW M3X8	1	86732
056	689099-4	HEAT SINK	1	
057	265995-6	TAPPING SCREW 4X18	2	
058	210022-4	BALL BEARING 626DDW	1	
059	240037-7	FAN 44	1	
060	643963-3	BRUSH HOLDER	1	
061	643964-1	BRUSH HOLDER	1	

# SPARE PARTS LIST

MODEL NO. BHR200

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
062	519066-4	ARMATURE ASS'Y 24V INC. 58,59,63	1	
063	210024-0	BALL BEARING 608LLU	1	
064	226793-3	ZEROL BEVEL GEAR 11	1	
065	632828-4	YOKE UNIT	1	
066	152624-9	GRIP 36 COMPLETE	1	
067	931202-6	HEX. NUT M5	1	
068	417294-4	GRIP BASE	1	
069	265720-5	THUMB SCREW M5X14	1	
070	344902-3	PLATE	1	
071	421750-8	SEAL RING B	1	
072	421749-3	SEAL RING A	1	
073	421748-5	SEAL RING	1	
074	344899-6	CHANGE PLATE	1	
075	345457-1	GUIDE PLATE	1	
076	266020-6	TAPPING SCREW 4X12	2	
077	417292-8	F/R CHANGE LEVER	1	
078	344903-1	VIBRATION ISOLATOR PLATE	1	
079	417297-8	FOOT	1	
080	265995-6	TAPPING SCREW 4X18	2	
081	643941-3	BRUSH HOLDER CAP	2	
082	191971-3	CARBON BRUSH CB-430	1	
083	417293-6	CHANGE LEVER	1	
084	213265-7	O RING 17	1	
085	961078-7	RETAINING RING (EXT) S-18	1	
086	233279-0	COMPRESSION SPRING 4	1	
087	417298-6	LOCK BUTTON	1	
088	183891-5	HOUSING SET INC. 50,89	1	
089	819063-3	MAKITA LABEL	1	
090	233278-2	COMPRESSION SPRING 5	1	
091	685730-0	SPONGE	1	
092	345458-9	STOPPER PLATE	1	
093	345456-3	SUB PLATE	1	
094	231678-0	TORSION SPRING 9	1	
095	911110-7	PAN HEAD SCREW M4X8	1	
A01	181573-3	GREASE VESSEL 93G	1	
A02	321144-6	DEPTH GAUGE	1	
A03	824690-3	PLASTIC CARRYING CASE	1	
A04	193739-3	BATTERY BH2433 SET	1	
A05	***DC24WA	DC24WA BATTERY CHARGER	1	
B01	134901-1	GRIP 36 ASS'Y INC. 46,47,66-70	1	
B02	183474-1	SEAL RING SET INC. 71-73	1	
E01	193739-3	BATTERY BH2433 SET	1	
E02	688165-4	LINE FILTER	1	
E03	688172-7	LINE FILTER	1	

# SERVICE DRAWING

MODEL NO. BHR200

