

SPARE PARTS LIST

MODEL NO. 3901

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	911136-9	PAN HEAD SCREW M4X20	4	
002	221357-8	SPIRAL BEVEL GEAR 11	1	
003	213407-3	O RING 26	1	
004	211088-7	BALL BEARING 6000DDW	1	
005	341398-9	PLATE	1	
006	241509-5	FAN 60	1	
007	511908-8	ARMATURE ASS'Y 220V INC. 6,17,18	1	
008	911596-5	PAN HEAD SCREW M4X70	2	
009	593138-3	FIELD ASS'Y 220V	1	
010	159283-0	MOTOR HOUSING COMPLETE INC. 11	1	
011	263002-9	RUBBER PIN 4	1	
012	411328-5	SWITCH ROD	1	
013	257903-1	STOP RING E-2.3	1	
014	643550-8	BRUSH HOLDER CAP 5-8	2	
015	191940-4	CARBON BRUSH CB-411	1	
016	414663-0	SWITCH LEVER	1	
017	210025-8	BALL BEARING 627LLB	1	
018	681614-0	INSULATION WASHER	1	
019	415253-2	GRIP	1	
020	922422-3	HEX. SOCKET HEAD BOLT M8X16	2	
021	941202-8	FLAT WASHER 8	2	
022	157393-7	GEAR HOUSING COMPLETE INC. 3	1	
023	961052-5	RETAINING RING S-12	1	
024	221356-0	SPIRAL BEVEL GEAR 36	1	
025	962151-6	RETAINING RING R-32	1	
026	211106-1	BALL BEARING 6201LLB	1	
027	322658-8	SPINDLE	1	
028	322657-0	ROD 10	2	
029	251919-8	CAP SQUARE NECK BOLT M6X20	1	
030	316494-2	FENCE	1	
031	256689-4	PIN 4	2	
032	931102-0	HEX. NUT M4	1	
033	231795-6	TENSION SPRING 8	2	
034	231282-5	COMPRESSION SPRING 2.4	1	
035	216001-0	STEEL BALL 3.5	1	
036	253804-1	FLAT WASHER 6	1	
037	252133-9	HEX. NUT M6	1	
038	272229-0	LEVER 40	1	
039	961014-3	STOP RING E-8	1	
040	162163-1	RUBBER FACING	1	
041	961017-7	STOP RING E-3	2	
042	316496-8	BLADE COVER	1	
043	224505-8	LOCK NUT 10-40	1	
044	B-20644	CUTTER 100MMX6T	1	AEPD-001/100
045	224280-6	INNER FLANGE 40	1	
046	232131-9	LEAF SPRING	1	
047	265716-6	SCREW M5X10	1	
048	213008-7	O RING 22.4	1	
049	415252-4	DUST NOZZLE	1	
050	911198-7	PAN HEAD SCREW M4X70	2	
051	410190-5	REAR COVER	1	
052	666066-6	POWER SUPPLY CORD 1.0-2-2.5	1	
053	682502-4	CORD GUARD 8-85	1	
054	645173-8	NOISE SUPPRESSOR	1	
055	911111-5	PAN HEAD SCREW M4X10	2	
056	651651-8	SWITCH SS203KY-4	1	
057	231223-1	COMPRESSION SPRING 6	1	
058	316495-0	BASE	1	

SPARE PARTS LIST

MODEL NO. 3901

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
059	265026-1	+ PAN HEAD SCREW M4	1	
060	316491-8	STOPPER	1	
061	231282-5	COMPRESSION SPRING 2.4	1	
062	216001-0	STEEL BALL 3.5	1	
063	911136-9	PAN HEAD SCREW M4X20	4	
064	316493-4	BEARING BOX	1	
065	254002-0	WOODRUFF KEY 3	1	
066	911267-4	PAN HEAD SCREW M5X45	1	
067	911133-5	PAN HEAD SCREW M4X18	2	
068	410191-3	SWITCH HOLDER	1	
069	687001-1	STRAIN RELIEF	1	
070	911128-8	PAN HEAD SCREW M4X16	2	
071	687637-6	SET PLATE	1	
072	857433-8	NAME PLATE 3901	1	
073	931203-4	HEX. NUT M5	1	
A01	921332-1	HEX. BOLT M6X20	1	
A02	316492-6	CLAMP	1	
A03	150455-0	ANGLE GUIDE COMPLETE	1	
A04	226217-9	SPUR GEAR 16	1	
A05	961017-7	STOP RING E-3	1	
A06	253186-1	FLAT WASHER 7	1	
A07	271415-0	KNOB 20	1	
A08	232130-1	LEAF SPRING	1	
A09	253804-1	FLAT WASHER 6	1	
A10	252133-9	HEX. NUT M6	1	
A11	272229-0	LEVER 40	1	
A12	961014-3	STOP RING E-8	1	
A13	782401-1	LOCK NUT WRENCH 20	1	
A14	122474-6	DUST BAG ASS'Y	1	
A15	824540-2	PLASTIC CARRYING CASE	1	
A16	415579-2	SET PLATE 4	1	
B01	122473-8	ANGLE GUIDE ASS'Y INC. A01,A02,A03-A12	1	
E04	652008-6	PAN HEAD SCREW M3.5X7	4	
E05	652250-9	CLAMP WASHER	4	

SERVICE DRAWING

MODEL NO. 3901

