

# SPARE PARTS LIST

MODEL NO. BO5041

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	265995-6	TAPPING SCREW 4X18	5	
002	451619-2	TOP COVER	1	
003	265995-6	TAPPING SCREW 4X18	2	
004	645105-5	NOISE SUPPRESSOR	1	
005	687052-4	STRAIN RELIEF	1	
006	682502-4	CORD GUARD 8-85	1	
007	665383-1	POWER SUPPLY CORD 1.0-2-2.0	1	
008	191627-8	CARBON BRUSH CB-64	1	
009	643552-4	BRUSH HOLDER 5-8	2	
011	651286-5	SWITCH SGEL206C-5	1	
012	263002-9	RUBBER PIN 4	2	
013	451617-6	MOTOR HOUSING	1	
014	867887-1	BO5041 NAME PLATE	1	
015	633724-9	FIELD 240V	1	
016	266147-2	TAPPING SCREW 4X55	2	
017	210017-7	BALL BEARING 607DDW	1	
018	681652-2	INSULATION WASHER	1	
019	515734-7	ARMATURE ASS'Y 240V INC. 17,18,20,21	1	
020	267806-1	WASHER 9	1	
021	211092-6	BALL BEARING 629DDW	1	
022	450672-5	BRACKET	1	
023	265995-6	TAPPING SCREW 4X18	4	
024	241673-2	FAN 88	1	
025	267164-5	FLAT WASHER 15	1	
026	188835-0	SKIRT SET INC. 28	1	
027	265995-6	TAPPING SCREW 4X18	2	
028	188835-0	SKIRT SET INC. 26	1	
029	318304-9	BEARING BOX	1	
030	211228-7	BALL BEARING 6202DDW	1	
031	424131-5	BRAKE RING	1	
032	318303-1	BEARING BOX COVER	1	
033	253739-6	FLAT WASHER 4	1	
034	911128-8	PAN HEAD SCREW M4X16	1	
035	743081-8	PAD 123	1	
036	911128-8	PAN HEAD SCREW M4X16	3	
037	631956-2	CONTROLLER	1	
A01	125779-3	GRIP ASSEMBLY	1	
A02	166078-4	DUST BAG	1	
A03	257202-1	RING 25	1	
A04	416063-0	DUST BAG NOZZLE	1	
A05	416064-8	DUST NOZZLE	1	
A06	794544-7	ABRASIVE DISC 125 #120	1	
A07	824562-2	PLASTIC CARRYING CASE	1	

# SERVICE DRAWING

MODEL NO. BO5041

