



FIG. 2: CG260E SHOULDER BRUSH CUTTER



Ser. NO.	CODE	Part Name	Qty	Ser. NO.	CODE	Part Name	Qty
2-1	261201	FLEXIBLE SHAFT	1	2-33	261233	STOP RING 35	1
2-2	261202	BRACKET	1	2-34	261234	BEARING 6202-2RS/P5	2
2-3	261203	PIPE	1	2-35	261235	STOP RING 15	1
2-4	261204	SCREW M5*25	2	2-36	261236	LINKER	1
2-5	261205	HOLDER	1	2-37	261237	LEVER ASS'Y	1
2-6	261206	SAFETY GUARD	1	2-38	261238	CLAMP	1
2-7	261207	NUT M5	7	2-39	261239	RUBBER COVER	1
2-8	261208	SCREW	1	2-40	261240	BOX, RIGHE	1
2-9	261209	BERING 608-2RS/P5	2	2-41	261241	CLAMP	1
2-10	261210	PIPE	1	2-42	261242	SCREW M5*10	1
2-11	261211	SCREW M5*12	2	2-43	261243	TINE	1
2-12	261212	SCREW M5*20	2	2-44	261244	SPRING	1
2-13	261213	LINKCR	1	2-45	261245	SPRING	1
2-14	261214	HOLDER	1	2-46	261246	SPRING	1
2-15	261215	ROPE PULLY UP COVER		2-47	261247	SAFETY LEVER	1
2-16	261216	NYLON LINE	1	2-48	261248	THROEELT LEVER	1
2-17	261217	ROPE PULLY DOWN COVER		2-49	261249	CABLE COMP	1
2-18	261218	ROPE PULLY ASSY	1	2-50	261250	SCREW M5*20	1
2-19	261219	WASHER 8	1	2-51	261251	SCREW M5*30	1
2-20	261220	WASHER 8	1	2-52	261252	BOX, LEFT	1
2-21	261221	NUT M8	1	2-53	261253	STOP SWITCH	1
2-22	261222	BUSH	1	2-54	261254	TUBE	1
2-23	261223	HANDLE ASS' Y	1	2-55	261255	RUBBER COVER	1
2-24	261224	HANDLE ASS' Y	1	2-56	261256	CLAMP B	1
2-25	261225	HANDLE COVER	1	2-57	261257	CLAMP A	1
2-26	261226	SCREW M5*35	4	2-58	261258	WASHER 6	4
2-27	261227	SCREW M5*16	2	2-59	261259	WASHER 6	4
2-28	261228	NUT M5	2	2-60	261260	SCREW M6*20	4
2-29	261229	BLADE	1	2-61	261261	SCREW M5*25	2
2-30	261230	BUSH	1	2-62	261262	WASHER 5	6
2-31	261231	CLUTCH COMP	1	2-63	261263	WASHER 5	6
2-32	261232	CLUTCH DRUM COMP	1	2-64	261264	SCREW M5*16	2

FIG. 1: 1E34F GASLINE ENGINE



Ser. NO.	CODE	Part Name	Qty	Ser. NO.	CODE	Part Name	Qty
1-1	261101	SCREW	1	1-40	261140	STARTER PAWL SPRING	1
1-2	261102	CLEANER OUTSIDE COIVER	1	1-41	261141	STARTER PAWL	1
1-3	261103	FILTER	1	1-42	261142	STARTER	1
1-4	261104	SCREW ASSY M5X55	2	1-43	261143	SCREW ASSY M5X14	1
1-5	261105	CLEANER OUTSIDE COIVER	1	1-44	261144	COVER	1
1-6	261106	SCREW ST4X10	2	1-45	261145	COVER	1
1-7	261107	CHOKE	1	1-46	261146	SCREW ASSY M4X12	1
1-8	261108	CHOKE HANDLE	1	1-47	261147	COVER, plug	1
1-9	261109	CARBURETOR	1	1-48	261148	PLUG	1
1-10	261110	GASKET, carburetor side	1	1-49	261149	SCREW M5X20	4
1-11	261111	SCREW ASSY M5X20	6	1-50	261150	GASKET, muffler	1
1-12	261112	INLET MANIFOLD	1	1-51	261151	MUFFLER	1
1-13	261113	WASHER, cylinder side	1	1-52	261152	SCREW M5X55	2
1-14	261114	PIN B3X10	4	1-53	261153	CYLINDER	1
1-15	261115	SCREW ASSY M4X16	9	1-54	261154	GASKET, cylinder	1
1-16	261116	FAN COVER	1	1-55	261155	RING, piston	2
1-17	261117	CLUTCH STEP SCREW	2	1-56	261156	PISTON	1
1-18	261118	WASHER	2	1-57	261157	KEY	1
1-19	261119	CLUTCH ASSY	1	1-58	261158	STOP RING	2
1-20	261120	CLUTCH	2	1-59	261159	PIN, piston	1
1-21	261121	SPRING, clutch	1	1-60	261160	NEEDLE, bearing	1
1-22	261122	WASHER 6X15X1	2	1-61	261161	PISTON PIN CIRCLLET	2
1-23	261123	NUT M8X1	1	1-62	261162	FUEL TANK CAP ASSY	1
1-24	261124	STOP CORD COMP.	1	1-63	261163	FUEL TANK CAP	1
1-25	261125	PRIMARY CORD GROMMET	1	1-64	261164	AIR INLET MOUTH	1
1-26	261126	MAGNETO STATOR	1	1-65	261165	FRAME	1
1-27	261127	MAGNETO ROTOR	1	1-66	261166	GASKET, fuel tank cap	1
1-28	261128	SCREW M5X25	4	1-67	261167	ANTI-RUN SEAT	1
1-29	261129	WASHER 5	6	1-68	261168	ANTI-RUN CHAIN	1
1-30	261130	WASHER 5	6	1-69	261169	FUEL TANK	1
1-31	261131	FRONT HALF CRANKCASE	1	1-70	261170	WASHER 5	3
1-32	261132	GUIDE PLATE	1	1-71	261171	SCREW M5X16	2
1-33	261133	GASKET, crankcase	1	1-72	261172	SCREW M5X20	1
1-34	261134	OIL SEAL 12X22X7	2	1-73	261173	CLEANER	1
1-35	261135	BALL-BEARING 6001/P5	2	1-74	261174	PRIMARY CORD GROMMET	1
1-36	261136	CRANKSHAFT COMP.	1	1-75	261175	INLET FUEL PIPE	1
1-37	261137	REAR HALF CRANKCASE	1	1-76	261176	OUTLET FUEL PIPE	1
1-38	261138	STARTER PULLEY ASSY	1	1-77	261177	PLUG CAP	1
1-39	261139	STARTER PULLEY	1				